

MATTERS NEED ATTENTION

1. Do not pull the power lines or cover it with clothing items, or put burning cigarette on the body, in order to avoid fires or other accidents.
2. When mentally handicapped person and children use the machine, the guardian must be their side, or it could be dangerous.
3. Please do not use wet hands to plug on or plug off switch and power lines, avoiding electrical shock
4. When Maintenance you should prevent the water drop into the machines, in order to avoid electric shock or short circuit.
5. Do not put wet clothes on the mouth

WARNING

1. It is forbidden to use your hands or other matter to block up the spout, or use extension matter like iron wire to insert the in the spout.
2. It is forbidden to use your hands or other matter to block up the spout, or use extension matter like iron wire to insert the in the spout.
3. Do not decompose, repair or any alteration of this machine without authorization, or put burning cigarette on the body, otherwise there is a risk of electric shock, fire and other accidents.
4. If the power software cord is damaged, it should be replaced with specialized software or buy components from factories or dedicated maintenance.